

1:Connect the lamp wires to the reserved wires

2:Fix the lamp body to the ceiling with screws

3:The lampshade is bent from the bottom and inserted into the lamp body

